

Petroff Sony PMWEX1 Lens Isert



The insert is designed to snap over the lens bayonet. The **flat site** of the insert pointing the camera.

Stretch the lens insert and place it in the slot behind the lens bayonet. Rotate the lens insert until the lens insert **slot** is placed over the little protruding **rib** that serves as the orientation stop for the original lens shade.

